

These instructions enable the actuator to be configured to suit the valve and must be carried out before electrical start up. For complete instructions see the installation manual that shipped with the actuator or refer to the publications listed below.

Old Rotork Setting Tools and new Setting Tool *Pro*'s are fully compatible with all IQ range actuators.

If an old Rotork Setting Tool is used with an IQ *Pro*/IQT *Pro* actuator the data download/upload facility will not be available. Navigation through the menu structure is facilitated using the 'down' and 'right' arrow keys. At the end of a menu section pressing the arrow right or arrow down key, as applicable, will return the menu to the start.

If a new Setting Tool *Pro* is used with an IQ actuator (an actuator without 'split screen' text support) the 'back arrow' and data upload/download facility will be unavailable.

For further configuration and settings the following publications are available:

IQ mk 1 actuator	-	E170E
IQ mk 2 actuator	-	E170E2
IQ <i>Pro</i> actuator	-	E170E3
IQT actuator	-	E175E
IQT <i>Pro</i> actuator	-	E175E3


1 Old (non-textual) Display



Fig. 1.1 IQ non-textual display

If your actuator is fitted with the old Rotork IQ or IQT main board, your display will appear as fig 1.1. If so then follow the instructions in sections 5 and 7 to set the basic configurations for your actuator.

2 Old Rotork Setting Tool



The Old Rotork Setting Tool

1. ↓ Key* Display next function down
2. ➡ Key* Display next function across
3. − Key Decrease/change displayed function's value or option setting
4. + Key Increase/change displayed function's value or option setting
5. ⬅ Key Enter displayed value or option setting

* Pressing the two arrow keys together returns the actuator display to the position indication mode

Infra-red local operation (when enabled)

5. ⬅ Key Stop actuator
6. ☰ Key Open actuator
7. ☶ Key Close actuator
8. Infra-red Transmitter Window


3 New *Pro* Display



Fig. 2.1 IQ *Pro* display

If your actuator is fitted with the new Rotork IQ or IQT *Pro* main board, your display will appear as fig 2.1. If so then follow the instructions in sections 6 and 8 to set the basic configurations for your actuator.

4 New Setting Tool *Pro*



The Setting Tool *Pro* (new version)

1. ↓ Key* Display next function down
2. ↑ Key Display previous function up
3. ➡ Key* Display next function across
4. ⬅ Key Display previous function across
5. − Key Decrease/change displayed function's value or option setting
6. + Key Increase/change displayed function's value or option setting
7. ⬇ Key Initiate download/upload mode
8. ⬅ Key Enter displayed value or option setting

* Pressing these two arrow keys together returns the actuator display to the position indication mode


Infra-red local operation (when enabled)

9. ⬅ Key Stop actuator
10. ☰ Key Open actuator
11. ☶ Key Close actuator
12. Infra-red Transmitter Window

Basic Setting Instructions for IQ and IQT Actuators

5


Basic Setting Instructions — Old (non-textual) Display



Basic Setting Instructions for IQ and IQT Actuators

6

Basic Setting Instructions — New Pro Display




Basic Setting Instructions for IQ and IQT Actuators

Check List — Old (non-textual) Display


Checking actuator settings requires the use of  and  keys only. Displays on actuator show set values. Return to the start of the setting procedure (Position Display) by pressing  and  together. Checking may be carried out with the actuator in either Setting or Checking mode.



Until C1 (DIRECTION TO CLOSE)
is displayed




Clock




Anti-clock



To display C2 (CLOSE ACTION)



Limit




Torque



To display C3 (OPEN ACTION)




Limit



Torque




To display t C
(TORQUE VALUE CLOSING)



Display shows
selected torque



To display t O
(TORQUE VALUE OPENING)



Display shows
selected torque

Press  and  together to return to Position Display and move valve to fully closed condition checking that closed symbol and lamp appear just as the limit of travel is reached.

Move valve to fully open position checking that open symbol and lamp appear just as the limit of travel is reached.

8

Check List — New Pro Display

Checking actuator settings requires the use of  and  keys only. Displays on actuator show set values. Return to the start of the setting procedure (Position Display) by pressing  and  together. Checking may be carried out with the actuator in either Setting or Checking mode.



Until C1 (DIRECTION TO CLOSE)
is displayed



Clock



Anti-clock



To display C2 (CLOSE ACTION)



Limit



Torque



To display C3 (OPEN ACTION)




Limit



Torque




To display t C
(TORQUE VALUE CLOSING)



Display shows
selected torque
e.g. 40%



To display t O
(TORQUE VALUE OPENING)



Display shows
selected torque
e.g. 40%

Press  and  together to return to Position Display and move valve to fully closed condition checking that closed symbol and lamp appear just as the limit of travel is reached.

Move valve to fully open position checking that open symbol and lamp appear just as the limit of travel is reached.

rotork®

UK head office
Rotork Controls Limited
telephone Bath 01225 733200
telefax 01225 333467
email mail@rotork.co.uk

USA head office
Rotork Controls Inc
telephone Rochester (585) 247 2304
telefax (585) 247 2308
email info@rotork.com



Rotork Controls Ltd, Bath, UK



Rotork Controls Inc, Rochester, USA

As part of a process of on-going product development, Rotork reserves the right to amend and change specifications without prior notice.

Published data may be subject to change.

For the very latest version release, visit our website at www.rotork.com

The name Rotork is a registered trademark. Rotork recognizes all registered trademarks. Published and produced in the UK by Rotork Controls Limited. POWTG0306

A full listing of our worldwide sales and service network is available on our website at www.rotork.com